

**G | S | M**

Gerard Sourcing &amp; Manufacturing

**DETAILS**

Project Name/Model : MA01021

Project Type : Color Box

Request By : Tommy Wong

Size : 295(W) x 295(H) mm

Start Date : 14 Feb 2018

Revised Date : 06 April 2018

Finish Date :

Drawing By : Siva Fong

**COLOURS**

CMYK



BLACK

Pantone



DIELINE

**FINISH**

Gloss Lamination

*mistral***Expressaire 250mm Self-Closing Exhaust Fan****Instruction Manual**

Model: MA01021

**Important Safeguards**

When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should always be followed, including:

**For Your Safety**

Read all instructions carefully, even if you are quite familiar with the appliance.

- Young children must be supervised to ensure that they do not play with the appliance.
- To disconnect, grip the plug and pull it from the wall outlet. Never pull by the cord. Do not use with wet hands or in damp environments.
- If the supply cord is damaged, it must be replaced before further use by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance is for indoor use only.
- Do not allow ceiling insulation to cover any part of the rear of this appliance.
- Do not put any type of speed control device in line with the fan's power supply.
- Do not attempt to modify this appliance.
- Do not place any subject or body part into the fan while it is operating.
- Do not clean the device while it is plugged in.
- Do not install the device in an environment that suffers from water leakage.
- Other than the removable blade assembly, there are no user serviceable parts in the appliance. Do not attempt to repair.
- Do not immerse the motor in any liquid.
- Do not insert or allow foreign objects to enter any grille opening, as this may cause damage to the unit and/or injury to the user.
  - Remove all packaging and check the appliance for any damages during transportation.
  - Do not use if there are visible signs of damaged to the appliance.

**Warning**

If the supply power cord is damaged, the power cord must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

This product has not been designed for any uses other than those specified in this booklet.

**Save These Instructions****Before You Start**

This exhaust fan must be mounted more than 20cm from the side walls of room, more than 30cm from the top of the ceiling cavity and more than 2.3m away from the floor.

Only mount this exhaust fan in a flat ceiling. Do not mount on an angle, in curved ceilings or in vertical walls.

Make sure no electrical cables are in the way before you cut the mounting hole.

Any electrical work including the installation of switches, wiring and socket outlets must be carried out by a licenced electrician.

In accordance with the as/NZS 3000 wiring rules, the wall switch must not be installed where it can be reached by a person in the bath or shower.

Do not modify any structural component of the building in any way to install the exhaust fan

Do not install anywhere where water may be splashed into the exhaust fan.

Any air that is removed from the room by the fan must be replaced by an equivalent amount of air from outside the room - either through slightly open windows, under a door or similar. The more sealed the room is, the more degraded the exhaust fans performance will be.


This fan may be ducted if the ducting is stiff, and does not impede the self-closing fins. Any applicable building codes must be adhered to.

*mistral***Expressaire 250mm Self-Closing Exhaust Fan****Instruction Manual**

Model: MA01021

**Instruction**

1. Use this card to trace the outline of the hole onto the ceiling, using the centre punch for guidance.
2. Cut out the mounting hole.
3. Plug the fan into the power socket installed within the roof cavity.
4. Retract the three mounting clips on the outside of the fan and insert the fan into the ceiling cut out.
5. Rotate the screws. The mounting clips will rotate and hold the fan in place.
6. Tighten the screws to fasten the fan into place.
7. Switch on the fan to ensure it is working.
8. Switch off the fan and push the supplied screw hole covers over the screws.

**Cleaning**

Ensure the fan is switched off at the mains before attempting any cleaning.

1. Remove the fan blade assembly by unscrewing the central knob.
2. Wash the fan blade assembly in warm soapy water, then rinse clear.
3. Allow fan blade assembly to dry completely.
4. Replace fan blade assembly onto motor housing.

**Technical Specifications**

Power Supply: AC 220-240V~ 50Hz

Motor power: 40 Watts

Power Consumption: 40W

Airflow: 750 m<sup>3</sup>/h

Fan Speed: 1250 RPM

Fan diameter: 250mm

**NOTE: As a result of continual improvements, the design and specifications of the product within may differ slightly to the unit illustrated on the packaging. If any household fixed wiring becomes necessary, it must be carried out by a licensed electrician.**

**Warranty Conditions for purchase in Australia & New Zealand**

Any claim under this warranty must be made within 12 months of the date of purchase of the product. To make a claim under the warranty in Australia, take the product (with proof of purchase) to any Bunnings store (see [www.bunnings.com.au](http://www.bunnings.com.au) in Australia or [www.bunnings.co.nz](http://www.bunnings.co.nz) in New Zealand for store locations).

GSM Sales Pty Ltd bears reasonable, direct, expenses of claiming under the warranty in Australia. You may submit details and proof to a Bunnings store for consideration or contact our service agent below.

This warranty is provided in addition to other rights and remedies you may have under law: our goods come with guarantees which cannot be excluded under the Australian Consumer Law (if purchased in Australia) or the Consumer Guarantees Act 1993 (if purchased in New Zealand). You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The warranty excludes damage resulting from product misuse or product neglect. The warranty covers domestic use only and does not apply to commercial applications.

This warranty is given by GSM Sales Pty Ltd

ABN: 53007682475

For Warranty and technical queries: 1300 373 199 Aus or 0800 200 037 NZ

**Warranty Exclusions**

Damage to the base or diffuser or any part through accident, misuse or negligence.

**G | S | M**

Gerard Sourcing &amp; Manufacturing

**GSM Sales Pty Ltd**

Consumer Service Centre :

Aus: 1300 373 199

NZ: 0800 200 037

The GSM Sales Pty Group of Companies has a policy of continual improvement throughout the product range.

As such the unit contained within may differ slightly from the unit illustrated on the pack.

MADE IN CHINA for GSM Sales Pty Ltd. Group of Companies

Cat. No. MA01021  
April 2018